



PREPARATION AND APPLICATION PROCEDURE

STONE EFFECT COATING

PREPARATION	FINISH COATING	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none">- Rinse the surface well with a pressure washer.- Apply TexNov Surface Preparer according to the dilution table.- Brush the surface vigorously and leave for 15 minutes.- Rinse the surface thoroughly with a pressure washer.- Allow the surface to dry for 24 hours in good weather before applying the finishing coat.	<p>Procedure:</p> <ul style="list-style-type: none">- Apply 2 coats of TexNov Acrylic Coating, using a brush or roller with 10 mm bristles.- Allow 24 hours drying time between coats.- Allow the surface to dry for 24 hours before applying the sealant.	<p>Procedure:</p> <ul style="list-style-type: none">- Apply 2 coats of Met-30 TexNov sealer, using a brush or roller with 10 mm bristles.- Allow 24 hours of good weather to dry between coats.- Let the surface dry for 24 hours.

Maintenance: Clean the surface with *TexNov Surface Preparer* by diluting 9 parts of water and 1 part of *Preparer*. Let dry and add a coat of *Met-30 Sealer* every 3 years or as needed, which should allow you to keep your surface in good condition

