



PREPARATION AND APPLICATION PROCEDURE

ALUMINIUM SIDING

PREPARATION	FINISH	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none">- Rinse the surface well with a 2000 lb. pressure washer.- Apply and scrub the TexNov Surface Preparer.- Let act for 15 minutes by keeping the surface wet.- Rinse the surface thoroughly with a pressure washer.- Let the surface dry for 24 hours prior to applying the finish coating. <p>Note: In places where there is rust, apply a primer to metal previously.</p>	<p>After preparing the surface:</p> <p>Procedure:</p> <ul style="list-style-type: none">- In warm weather dilute with water (50 ml/liter) for ease of application.- <u>The temperature of the surface should not exceed 30° C at the application.</u>- Apply 2 coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between applying each coat).- Let the surface dry for 24 hours.	<p>After preparing the surface and applying the coating:</p> <p>Procedure:</p> <ul style="list-style-type: none">- To obtain a surface that will remain beautiful for a long time, apply TexNov Met-30 Sealant or TexNov WRS-40 Sealant for horizontal surfaces. Use a brush or roller with 10 mm bristles or a sprayer.- Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **Met-30 Sealant**.

