



PREPARATION AND APPLICATION PROCEDURE

CRESS PLYWOOD / PLY PANEL

PREPARATION	ADHESION MEMBRANE	FINISH	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none"> - Clean with TexNov Surface Preparer. - Let the surface dry for 48 hours. - Sand well to roughen the surface (with 60 grain sandpaper). - Caulk your joints with elastomeric polyurethane caulking (e.g.: Adbond 009, Sonneborn NP1 caulking or equivalent) taking care to caulk only the joints. 	<p>Procedure :</p> <ul style="list-style-type: none"> - Apply one coat of TexPro FlexStop RLX on the substrate. Use a brush or roller with 10 mm bristles. - Let the surface dry for 24 hours. 	<p>After preparing the surface and applying the sealant.</p> <p>Procedure:</p> <ul style="list-style-type: none"> - In warm weather dilute with water (50 ml / liter) for ease of application. - You can fill the screw heads with TexNov Acrylic Coating (screws should be rust proof: zinc, ceramic). - Apply 2 coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between applying each coat). - Let the surface dry for 24 hours before applying the sealant. <p>Note: TexNov Acrylic Coating will not hide all defects due to an unevenly installed substrate.</p>	<p>For horizontal surfaces:</p> <p>Procedure:</p> <ul style="list-style-type: none"> - Apply 2 coats of Met-30 Sealant. Use a brush or roller with 10 mm bristles (24 hours between each coat). - Let the surface dry for 24 hours. <p>Note: All wood surfaces located less than 60" from the ground or poorly ventilated should ideally be sealed on all sides with Met-30 Sealant. This will prevent premature deterioration of the wood due to the migration of moisture from the ground to the sky.</p>

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **Met-30** Sealant every 3 years or as needed. This should enable you to keep your surface in good condition.

