



# PREPARATION AND APPLICATION PROCEDURE

## AGGREGATE

PREPARATION	FINISH	SEALANT
<p><b>Procedure:</b></p> <ul style="list-style-type: none"> <li>- Clean the surface with a pressure washer</li> <li>- Note that if the concrete surface is dry, moisten before applying the <b>TexNov Surface Preparer</b>.</li> <li>- <b>TexNov Surface Preparer</b> can be applied with a sprayer.</li> <li>• Rinse with a pressure washer.</li> <li>- Let the surface dry for 24 hours prior to applying the finish coating.</li> </ul> <p><b>Note:</b> Repair cracks if needed with <b>TexNov All-purpose Polymer</b>.</p>	<p><b>Procedure:</b></p> <ul style="list-style-type: none"> <li>- Apply 2 coats of <b>TexNov Acrylic Coating</b>. Use a brush or roller with 10 mm bristles (24 hours between applying each coat).</li> <li>- Let the surface dry for 24 hours before applying the sealant.</li> </ul> <p><b>Note:</b> The appearance of your wall will be of uniform colour while retaining the rustic appearance of the aggregate.</p>	<p><b>Procedure:</b></p> <ul style="list-style-type: none"> <li>- You can apply TexNov WRS-40 Sealant (waterproof sealant) to waterproof the surface. (Optional)</li> <li>Use a brush or a roller with 10 mm bristles or sprayer</li> <li>- Let the surface dry for 24 hours.</li> </ul>

**Maintenance:** Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **WRS-40 Sealant** every 5 years or as needed. This should enable you to keep your surface in good condition.

