



PREPARATION AND APPLICATION PROCEDURE

CONCRETE FOUNDATION

PREPARATION	FINISH
<p>Procedure:</p> <ul style="list-style-type: none">- If your Foundation is covered with old roughcast which is coming off or any other unstable materials, remove them by using the appropriate tools. Remove any paint using a sandblaster, a diamond grinder or any other suitable means.- Clean the surface with a 3500 lb., rotary, jet pressure washer, gasoline motor. (Available at tool rental centers.)- In a clean container, dilute TexNov Concrete Conditioner with 50% water.- The concrete surface must be wet when applying the TexNov Concrete Conditioner.- Apply the TexNov Surface Cleaner Mix. on the surface with a sprayer and leave on for 10 to 15 minutes as needed brush vigorously and rinse thoroughly with a pressure washer- Let the surface dry for 48 hours of good weather.- Repair cracks with TexNov All Purpose Polymer or TexNov 200.- Apply a layer of TexNov All Purpose Polymer OR TexNov 200 before the application of the finishing coat.- Allow the surface to dry for 24 hours. <p>Note:</p> <ul style="list-style-type: none">- All imperfections, metal rods, etc... must be repaired with TexNov Polymer or TexNov 200 before applying the finishing coat for a uniform result.- For a flawless result, it is recommended to install one to two coats of TexNov 200 incorporating a fiberglass mesh. We must sand the traces of trowels visible later.	<p>Procedure:</p> <ul style="list-style-type: none">- Apply two coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between each coat).- In warm weather dilute with water (50 ml / liter) for ease of application.

Maintenance: Clean the surface with **TexNov Surface Preparer** (4 water / 1 Preparer).

