



PREPARATION AND APPLICATION PROCEDURE

MASONITE AND CANXEL (CLAPBOARD)

PREPARATION	SEALANT	FINISH
<p>Procedure:</p> <ul style="list-style-type: none"> - Rinse the surface thoroughly with a pressure washer. - Clean with TexNov Surface preparer. - Vigorously brush the surface and let sit for 15 minutes keeping the surface wet. - Rinse the surface thoroughly with a pressure washer. - Let the surface dry over a 48-hour period of good weather. 	<p>After preparing the surface:</p> <p>Procedure:</p> <ul style="list-style-type: none"> - In warm weather dilute with water (50 ml/liter) for <u>ease of application</u>. - Onto the Masonite if the surface is cardboard, apply a coat of TexNov Met-30 Sealant before applying the coating, otherwise rings will appear on the surface. Use a brush or roller with 10 mm bristles (24 hours between each coat). - Let the surface dry for 24 hours. 	<p>After preparing the surface and sealant (if necessary):</p> <p>Procedure:</p> <ul style="list-style-type: none"> - Apply two coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between each coat). - Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).

